

# IR Remote Codes

## JBL MA310/MA510/MA710/MA7100HP/MA9100HP

20250414 V1.1



### Protocol

#### Setup

- NEC Format
- Address: 8070H

#### Remote codes

KEY	CODE	Model
Power Toggle	0xC0	(All models)
Up	0x99	(All models)
Left	0xC1	(All models)
Select	0x84	(All models)
Right	0xc2	(All models)
Down	0x9a	(All models)
Back	0x85	(All models)
Dim	0x93	(All models)
Menu	0x53	(All models)
Vol Up	0xc7	(All models)
Vol Dn	0xc8	(All models)
Source Dn	0x30	(All models)
Surround Right	0x2f	(All models)
Mute	0xc3	(All models)
Surround Left	0x2e	(All models)
Source Up	0x31	(All models)
EXTENDED SET OF CODES		
Main Zone Power On	0x9B	(All models)
Main Zone Power Off	0x9F	(All models)
Zone 2 Party mode On	0xCE	(MA710/MA7100HP/9100HP only)
Zone 2 Party mode Off	0xD1	(MA710/MA7100HP/9100HP only)
Zone 2 Party mode Vol-up	0x9C	(MA710/MA7100HP/9100HP only)
Zone 2 Party mode Vol-dn	0x9D	(MA710/MA7100HP/9100HP only)
Main Zone TV	0x8E	(All models)
Main Zone HDMI1	0x88	(All models)
Main Zone HDMI2	0x89	(All models)
Main Zone HDMI3	0x8A	(All models)
Main Zone HDMI4	0x8B	(All models)
Main Zone HDMI5	0x8C	(MA710/MA7100HP/9100HP only)
Main Zone HDMI6	0x8D	(MA710/MA7100HP/9100HP only)
Main Zone Coax	0x81	(All models)
Main Zone Optical	0xDB	(All models)
Main Zone Analog input 1	0xC4	(All models)
Main Zone Analog input 2	0xCC	(All models)
Main Zone Phono input	0xD0	(MA710/MA7100HP/9100HP only)
Main Zone BT input	0xCA	(All models)
Main Zone Network input	0xCB	(All models)

# Release Notes

V1.0

Initial release.

V1.1

Add extended set of codes